



DESCRIPTION OF PARTS



- ⑪ Battery Compartment
- ⑫ Neck Strap Loop
- ⑬ Flash Socket
- ⑭ Back Cover Lock



- ⑮ Distance Scale
- ⑯ Depth of Field Indicator
- ⑰ Diaphragm Scale
- ⑱ Diaphragm Pin
- ⑲ Aperture Control Pin